

2” Horizontal Measuring Instructions

*Record all your measurements Width X Length; this is how your new blinds will be ordered.

Inside Mount

1. Measure the exact inside width of the inside of the window frame/jamb in three places (top, middle, and bottom) rounding down to the nearest 1/8”. When your shades are manufactured 1/2” will be deducted from the width to accommodate for the brackets and allow for an easy installation.
2. Measure the height of the inside of the window frame/jamb in three places (left, center, and right) and use the longest length rounded up to the nearest 1/8” when ordering.

Outside Mount

1. Measure the exact width of the window molding/frame or how wide you would like the blind to be. Be sure to add at least 1 1/2” to each side to allow for coverage of unwanted light gaps. There is no set rule, just make sure you order the blind wide enough to cover the opening.
2. Measure the height you would like the blind to be, keep in mind when you order the headrail is included in the overall measurement of the blind, the overall finished measurement is from the top of the headrail to the very bottom of the bottomrail . It is recommended to add at least 4” to 5” to the height to cover unwanted light gaps.
3. If you are mounting on a door and there is a molding you will need 3/8” projection spacers to allow for clearance when your new blind is mounted. Additionally for door mounted blinds the request of hold downs is also recommended to help keep the blind stationary when in the down position.

